



Find a Voice  
helping people communicate

# Switches

### Time Latch Switch

TO 003, TO 005, TO 007

Add the benefits of modes of control (direct, latch, timed seconds, timed minutes) to the flexibility of a battery system and you have an excellent choice for one student to control one battery-powered device at a time.



### Squish Switch


TO 102

Very sensitive plush squeeze operated switch.



### Pal Pad Switch – Small, Medium, Large

TO 83, TO 84, TO 85, TO 86, TO 2932, TO 298



### Squeeze Switch

TO 109

Ergonomic and easy to operate.



### Jelly Bean Switch

TO 061, TO 077, TO 078, TO 166, TO 396

Press the colourful squishy surface to operate.



### Super Sensitive Saucer Switch

TO 103, TO 133

Tough plastic. Irresistible to touch, and super sensitive.



### Joggle Switch – Blue & Green & Red

TO 239, To 255, TO 256

TRAXSYS' Joggle Switch allows you to increase or decrease the force required to activate it. It measures 5". Joggle Switch has 15 different settings. Rotate the top to increase or decrease the force required for activation.



### Tash Buddy Button

TO 071, TO 072

A reliable, durable, colourful switch. Auditory and tactile feedback. 6.3 cm diameter.



**On/Off Switch**

TO 191, TO 192, TO 242

Robust wooden 'latching' switch.

**Wobble Switch**

TO 163, TO 168

Multi-directional switch that can be activated by any part of the body from any direction. The Access Wobble Switch is a very handy switch that is useful in many situations.

**Smoothie Switch**

TO 247, TO 357, TO 366, SW 001

This lovely, smooth switch is new. It has a low profile surface and is angled towards the learner to make it really easy for those with limited movement to press.

**Thumb Switch**

TO 160

Grip the cylindrical base in your hand and press the black button with your thumb for momentary switch operation.



### **Eagle Footswitch**

TO 258



### **Mini Switch**

TO 259

You can insert a picture, photograph or coloured paper into the transparent sleeve on top of this wooden switch. Pressing on the switch activates a reward



### **Power Link 4 Control Unit**

TO 295

Allows switch users to control up to 2 electrical appliances with single switches



### **Iswitch**

COMM 188

Gives access to iOS Switch control, switch adapted apps, music and photography



**Slimline Switch**

TO 367, SW 002

This large switch requires very little pressure to activate and can also be used as a foot switch



**Kajo Button Soft Switch**

TO 369

Soft foamed switch, velcro attachment with safety pin to attach onto textiles



**Vibe-Lite Switch**

SW 003

A switch that combines tactile and visual stimulation with ergonomic design.

